



---

## Matrix 3

USER INSTRUCTIONS

---



---

**INSAFE HELPDESK**  
**0800 52 63 88**  
**helpdesk@insafe.co.uk**

Enter each digit slowly and distinctly. The lock signals at each entry.

If a mistake is made press '#' to clear.

Factory-set Master code: 00-12345678 (Change immediately after installation).  
This code is for resetting the lock. Please keep it safe.


Factory-set Manager code: 01-123456 (Change immediately after installation).  
This code opens the lock and can add or delete a second (02) user if required.

## Opening the Lock for the first time

0 1 1 2 3 4 5 6

**Enter Manager ID and code (01-123456)**

the keypad will beep and flash green 3 times. 3 red flashes indicate wrong code (see "Wrong Try Penalty")



**Turn keypad clockwise 1/4 turn** within 3 seconds.

**Open safe**, turn handle, if any, and open safe door.

**Now change your Master and Manager code**

## Changing the Master Code

Enter each digit slowly and distinctly. The lock signals at each entry.

# 5 2

**Press #52** to put lock in program mode.

The green led will stay on during this process.

If the light goes out, restart the process

0 0  
1 2 3 4 5 6 7 8

**Enter ID (00) plus existing 8-digit code (12345678)**

0 0  
X X X X X X X X

**Enter ID (00) and new 8-digit code**

0 0  
X X X X X X X X

**Enter ID (00) and new 8-digit code again and press the purple button** to complete the process. The keypad will beep and flash green 3 times. 3 low beeps and 3 red LED flashes will indicate code not changed.





## Manager / User Code Change

---

**Remember:** Manager and User codes are 8 digits long (a fixed 2-digit ID followed by a changeable 6-digit PIN).

**Ensure door is open through the entire process (including testing).**

**# 5 2** Press **#52** to put lock in program mode. The green led will stay on during this process. If the light goes out, restart the process

**0 1 X X X X X X X** Enter user ID and current combination "01-xxxxxx"

**0 1 X X X X X X X** Enter user ID again followed by your new combination "01-xxxxxx"

**0 1 X X X X X X X** Enter ID and new combination again then press **purple button** to complete the process. The keypad will beep and flash green 3 times. 3 low beeps and 3 red LED flashes will indicate code not changed

**Test the code** by opening and closing the lock with the door in the open position.

## Adding 02 User Code

---

**# 5 0** Press **#50** to enter Add User Mode. The green led will stay on during this process. If the light goes out, restart the process

**0 1 X X X X X X X** Input Manager code (01-xxxxxx)


**0 2 X X X X X X X** Input new user ID and code (02-xxxxxx)



**2 1** Press **2 then 1, followed by the purple button** to complete the process. The keypad will beep and flash green 3 times. 3 low beeps and 3 red LED flashes will indicate code not added.


**CODE MUST BE CHANGED BY THE USER BEFORE THE LOCK CAN BE OPENED.**

## Deleting 02 User Code

---

 **Press #56** to enter Delete User Mode

 **Input Manager code (01-xxxxxx) followed by 02**  


 **Press purple button.** The keypad will beep and flash green 3 times. 3 low beeps and 3 red LED flashes will indicate code not deleted.

## Wrong Try Penalty

---

The entry of four consecutive invalid combinations will start a 5-minute penalty period. The keypad will not operate during this period.

## Changing Batteries

---

1. Remove battery box located at the bottom of the keypad by pressing the button. The spring-loaded mechanism will partially eject the battery pack out of the keypad.
2. Remove old batteries and install new 9 vdc ALKALINE only, e.g. Energizer or Duracell batteries.
3. Reinstall battery pack.

**In case of difficulty, call the Insafe Helpdesk on 0800 526388**

**INSAFE.COM**  
SALES & SERVICE • SALES@INSAFE.CO.UK  
**0800 52 63 88**