

Installation of wall mounted Bobi letter boxes

Please note that according to the European standard for letter boxes, EN 13724:2002, a mounted height of between 0.7 and 1.7 meter for the aperture is recommended.

To install a **wall mounted letter box**, you will need:

1. a drill
2. a 6mm drill bit made from hardened steel
3. an old towel
4. a vacuum cleaner
5. a screwdriver
6. a tape measure



Place the letterbox face down onto the towel. Drill out the 4 preformed holes which are in the back of the letter box.



Using a 6mm drill bit made from hardened steel.



Please note it's important to drill at low speed, with a maximum of 500 rounds per minute. Do not apply too much pressure during drilling.



Carefully clean the holes and remove all metal remnants from the inside of the letterbox. We recommend using a vacuum cleaner to ensure all the small metal parts are removed from the holes, seams and bottom of the letterbox.



Please check the height of the letterbox. We advise to have the aperture of the letterbox at approximately 1 meter from the ground.



Use a screwdriver to fasten the parts together and tighten the screws from inside the letterbox. Please ensure there are no gaps between the wall or fence and the letterbox.

The result is a sturdy wall mounted post box.

Any metal remnants can, over time, lead to rust on the inside of your letterbox. Especially in the white coated letterbox this can cause unsightly marks.