

# BT Mini Lock Fitting Instructions

**Warning:** Under no circumstances should you use this Mini Lock or any other type of Hitchlock when actually travelling.



1. Insert dummy ring plate when trailer is unhitched by lifting handle and pushing into place.



2. Position chains to allow bottom channel to pass over easily.



3. Offer up bottom channel with the tail fill in strip at the front. Ensure the chain does not infringe on the hole as it will prove difficult to insert the lockbar.



4. Place the red top box over the bottom channel and lower until holes line up. Insert Bulldog Super Lock Bolt through holes and put cap over the end. Turn key quarter turn clockwise to lock and remove key.

**WARNING:** Before unlocking Mini Lock with keys provided, please remember to support base with hand **I.e Mind your feet**

## Bulldog Security Products

Units 1 - 4 Stretton Road, Much Wenlock, Shropshire, TF13 6DH.

Tel: 01952 728171 Fax: 01952 728117

Email [sales@bulldogsecure.com](mailto:sales@bulldogsecure.com) [www.bulldogsecure.com](http://www.bulldogsecure.com)

## Lock Lubrication.

**IMPORTANT** - To ensure free movement of the lock, spray lock mechanism & ball bearings with WD40 (or equivalent) minimum every four months.