COMBINATION CODE LOCK INSTRUCTION HOW TO SET YOUR OPENING COMBINATION

You can set your own personal combination by following these instructions:

The opening combination is preset at 0-0-0-.

- 1. Turn the dials to the preset combination 0-0-0.
- Move the reset button to position B as shown in picture I.
 The reset button is inside the cash box on the back of the lock mechanism.
- 3. Turn the dials to set your desired combination, and write down immediately, so you don't forget.
- 4. Move the reset button back to position A as shown in picture 2.

The lock will now open to your own combination.

To change your combination repeat steps 1-4 above.

