



# Instructions for digital Torino GMT/4P and GMT/7P with "ON" key to activate

Please read all of these instructions carefully before commencing using your safe. Try all of these procedures with the door open first, until you are familiar with how the safe works.

**WARNING!**  
**NEVER LEAVE YOUR  
EMERGENCY KEY IN THE SAFE**

## FEATURES

- High performance microprocessor
- Possible combinations: 10 billion
- Internal power supply with 4 x LR6 AA 1.5-v alkaline batteries
- Alphanumeric keyboard with 12 keys: 10 keys with numbers from 0 to 9 and 26 letters
- "ON" key to activate the circuit
- "ENTER" key to confirm code set
- The keyboard is of the membrane type with four dedicated LEDs, and contacts for external emergency power supply in the event of internal batteries being flat
- Internal button for programming new personal code
- **DIGITS THAT CAN BE SET** minimum 4 – maximum 10 digits in permanent memory  
(the "ENTER" and "ON" keys are not valid in the combination)

## INTRODUCTION

- ALL SAFES ARE PROVIDED WITH SERVICE CODE "1111"
- Before installing the safe, check that it works properly and read the instructions carefully to understand the operation
- Every time a key is pressed the green "OK" LED lights up and the buzzer sounds; pressing the "ENTER" key causes the green "OK" LED to light up for correct procedures, or the red "ERROR" LED to light up in the case of incorrect settings.

## INSTRUCTIONS FOR USE

1. Fit the 4 x 1.5-volt batteries (only alkaline batteries must be used) in its plastic seating on the back of the internal lock (see Pic. 1) and completely remove (without screwing it back in) the black screw marked with a special yellow label, which blocks the magnet.

2. **Test for opening using the service code "1111" (with door open and bolts extended)**

Press "ON", key in the service code "1111" and press "ENTER". The green "OK" LED lights up for about five seconds.

Within this time, with the green LED ON, turn the knob clockwise to retract the bolts.

If the combination is incorrect, the red "ERROR" LED will light up and the buzzer will sound.

After three attempts with incorrect codes, the keyboard will be disabled for one minute and this time will be indicated by the red "ERROR" LED flashing. After this time, renewed readiness for operation will be indicated by the green "OK" LED lighting up and a beep

## STORING THE PERSONAL CODE

3. **The procedure for storing the new code must be carried out with the door open and the bolts extended.**

- Press "ON"
- Press the programming button (see Pic. 2) near the top of the back of the door once; the button is marked with a yellow "PROGRAMMING" label  
The green "CODE" LED switches on with a steady light and stays on for 10 seconds

- Within 10 seconds, start keying in your new personal code (min. 4 – max. 10 digits) and press "ENTER"
- Key in your new code set again and press "ENTER" to confirm

If the procedure has been carried out correctly, a long sound with a number of tones is emitted, thus indicating that your code has been stored.

If errors have been made while setting your new code, this will be indicated by the red "ERROR" LED lighting up and a beep. Repeat the procedure for setting your new personal code again, starting from 3.

- *Before finally closing the safe, it is advisable to check that everything is OK by operating the opening and closing mechanism a number of times with the door open. Then shut the door and turn the knob anticlockwise until it is closed*

#### OPENING THE SAFE USING YOUR PERSONAL CODE

- Press "ON"
- Enter your personal code set earlier and press "ENTER". The green "OK" LED lights up for five seconds. Within this time, turn the knob clockwise and open the door

#### SIGNAL INDICATING THAT INTERNAL BATTERIES ARE GOING FLAT

When the internal battery begins to go flat, this is indicated at the end of the opening procedure, by the red "BATTERY" LED lighting up and a low beep tone. At this point, it will still be possible to open the safe a number of times. Replace the internal batteries with **4 x LLR6 AA 1.5V alkaline batteries**

#### EMERGENCY OPENING WITH INTERNAL BATTERIES FLAT

If the failing battery goes completely flat, as soon as the keyboard is pressed, the red "BATTERY" LED lights up and it is no longer possible to use the keyboard. To proceed with opening the safe, it is necessary to use a **new 9-volt LR61 alkaline battery** externally (see Pic. 3)

Press the **9-volt battery** contacts firmly on the corresponding contacts on the keyboards, ensuring that they are positioned correctly (the "-" of the battery touching the bigger contact and the "+" of the battery touching the small contact). With the battery firmly in position, key in code and open door. Replace internal batteries immediately.

#### CAUTION

Replace the 4 x LLR6 AA 1.5 V alkaline batteries every year

It must be remembered that even new, packed batteries can sometimes be defective, for various reasons, or have a brief duration. In the event of failure of the magnet release, or other faults, first of all, replace the battery with a new 4 x LR6 AA 1.5 V alkaline batteries (DURACELL LR6 AA is recommended)

The manufacture declines all responsibility for failure to observe the instructions given, or for improper use of the safe, thus causing the warranty to lapse.

*(Insert diagrams/line drawings.)*